


# How to Use this “Banknote+Coin WiFi”?

- 1 Switch off WiFi on your Phone**
- 2 Switch on WiFi and connect WiFi Name shown on machine screen**
- 3 Put your phone on the machine within 10 seconds, wait for “INSERT COIN” shown on screen**



WiFi Name:  
WiFi123  
Price:  
USD 1.00/60 min



13  
INSERT COIN  
INSERT BILL  
Remove phone pls

- 4 Remove your phone and then insert coins/ banknotes. Enjoy Internet.**



USD:1.00  
Time:01:00:00  
Remove phone pls